

## Troubleshooting

SYMPTOM	POSSIBLE REASON	SOLUTION
<p>Display turns ON, but does not show image.</p>	<p>Loose cable connections.</p> <p>-----</p> <p>Imager is broken.</p> <p>-----</p> <p>Imager head covered by debris.</p>	<p>Check cable connections, clean if required. Re-attach.</p> <p>-----</p> <p>Replace the Imager.</p> <p>-----</p> <p>Visually inspect imager head to make certain it is not covered by debris.</p>
<p>LEDs on imager head are dim at max brightness, display switches between black and white, color display turns itself OFF after a brief period.</p>	<p>Battery low on power.</p>	<p>Replace battery with charged battery.</p>
<p>Unit will not turn ON.</p>	<p>Dead battery.</p> <p>-----</p> <p>Unit need to be reset.</p>	<p>Replace with charged battery.</p> <p>-----</p> <p>Reset unit. See "Maintenance" Section.</p>